

YAMAHA SINGLE-AXIS ROBOT

F10

Maintenance Procedures

Maintenance Procedures

F10/F10-BK

Contents

About this document	1
Safety Information	1
Signal words used in this manual	1
Preparations	2
Maintenance procedures	3
1. Cautions before work	4
2. Removing cover	4
3. Removing brake	5
4. Removing motor	6
5. Removing ball screw	7
6. Installing ball screw	10
7. Installing motor	12
8. Installing brake	14
9. Assembling cover	16
10. Confirming after work	17
11. Confirming position shift	18

About this document

- YAMAHA shall not be held responsible for any trouble arising from incorrect use of this document.
- The work described in this document shall be conducted at the work personnel's risk after understanding the contents fully.
- Make sure to accept "Terms of Use for the Content" at the end of the document before use.

Safety Information

Strictly follow "Safety Instructions" in the manual.

Signal words used in this manual

This manual uses the following safety alert symbols and signal words to provide safety instructions that must be observed and to describe handling precautions, prohibited actions, and compulsory actions. Make sure you understand the meaning of each symbol and signal word and then read this manual.



DANGER

This indicates an immediately hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

This indicates potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

This indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury, or damage to the equipment.



NOTE

This explains the key point in the operation in a simple and clear manner.



Use a jig. (Refer to "Preparation" in this document.)



Use thread sealer.



Use a torque wrench.

Flow

Because of the actuator's structure, the order of disassembling is brake, motor, and ball screw, and all the procedures are described in this document. When replacing only brake (and motor), skip unnecessary steps (removing/installing ball screw, and so on).

Preparation

1. Replacement parts

Nº	Part Name	Part Number	Q'ty	Brake	Motor	Ball Screw	Remarks	
1	Brake	KX7-M4891-A0	1	○			For models with brake	
2	Set screw for brake hub	KX7-M2297-00	1	○	○	○	For models with brake	
3	Brake hub fixing bolt	KX7-M2296-00	1	○	○	○	For models with brake Left-hand thread M5-12	
4	Wave washer	KX5-M2294-00	1	○	○	○		
5	Motor	90K92-610230	1		○		100W	
6	Support bearing	KX7-M2232-00	1		○	○	Motor side	
7	Damper for adjusting grid position	Refer to Step2 of 10.			○	○		
8	Sim for adjusting grid position	Refer to Step2 of 10.			○	○		
9	Bearing	KX7-M2231-00	1			○	Angular bearing	
10	Support bearing	KX5-M2232-10	1			○	Non-motor side	
11	Cir clip	99009-12400	1			○	Non-motor side	
12	Key	90990-04J001	1			○	For ball screw	
13	Ball screw	F10-20-XXX	KX5-M2272-XX	1			○	Lead: 20 mm
		F10-10-XXX	KX5-M22P1-XX				○	Lead: 10 mm
		F10-05-XXX	KX5-M22P3-XX				○	Lead: 5 mm
		F10-20BK-XXX	KX5-M2271-XX				○	Lead: 20 mm
		F10-10BK-XXX	KX5-M2275-XX				○	Lead: 10 mm
		F10-05BK-XXX	KX5-M2279-XX				○	Lead: 5 mm

Note:

- Required parts depend on the item (brake, motor, ball screw) to be replaced.
"○" indicates the necessary part for replacing the item.
- Nº1 and Nº2 parts are required only for models with brake.
- The numbers in this document hereafter will refer to these tables.
For the parts without "○" indication, use the one originally installed.

2. Specialized Tools



	Name	Brake	Motor	Ball Screw	Remarks
A	Torque wrench	○	○	○	M3 for hex socket head bolt, 2·0 Nm (20 kgcm)
B	Torque wrench		○	○	M4 for hex socket head bolt, 3·8 Nm (38 kgcm)
C	Torque wrench			○	M5 for hex socket head bolt, 7·5 Nm (75 kgcm)
D	Torque wrench			○	M6 for hex socket head bolt, 13·0 Nm (130 kgcm)
E	Torque spanner	○	○	○	For spanner 14, 20·0 Nm (200 kgcm)

3. General Tools



Name	Part Number	Brake	Motor	Ball Screw	Remarks
Phillips screwdriver		○	○	○	
Hex keys		○	○	○	
Wrench (12mm/14mm)		○	○	○	
LOCTITE		○	○	○	Nº648 (Green) / Nº241 (Blue)
Plastic hammer			○	○	
Molybdenum grease	KV7-M718H-00			○	NET: 25g
Alvania grease	S02D-MTT01-000			○	NET: 400g
Jig for motor replacing	S01E-M6302-000		○	○	

4. Bolt indication

Indication example	Description
3 - M5 - 30	3 M5-size, 30mm-long hex socket head bolts
Q'ty - Size - Length	

Maintenance procedures

1. Cautions before work



WARNING

- At replacement, make sure to disconnect the robot and the controller or turn OFF the controller. If the robot moves during work, it may cause serious accidents.
- Only personnels trained by Yamaha or your distributor should remove the cover.
- Make sure to tighten all the screws and bolts. If the cover is not secured firmly, this may cause noise, cover dropping and flying, hand entanglement in drive unit during teaching, or burn due to hand in contact with hot surface.



CAUTION


- Be sure to wear safety gloves before starting the work. If you touch any steel material part with bare hands, this may cause rust.
- Be careful not to drop any screws and bolts when removing the cover and other parts.
(It is recommended to cover under the working area with a plastic sheet or something to avoid losing screws and bolts.)

2. Removing cover

Step 1 Connect the robot and controller.

Move the robot to the point where the coordinate on the controller is 0 mm with a handy terminal or else. Then tape between the carriage and frame, mark straight lines, and cut the between them with a cutter or something.


▶ Step 1 Marking



Step 2 Remove the screws (4-M4-8) to take off the upper cover. Remove the screws (8-M4-8) on the motor side, then take off the motor cover and end cover.

Skip to "4. Removing motor" when replacing the motor and ball screw of robot without brake.

▶ Step 2 Removing cover



3. Removing brake



Step 1 Removing brake

Step 1 Take measures to prevent the robot from dropping. Otherwise, remove the robot from the base and place horizontally. Remove the grommet and brake cover, and then the brake fixing bolts (3-M3-35). Remove the brake slowly as the spacers easily drop, and take care not to lose the bolts and spacers.





DANGER

Removing the brake with the robot installed vertically may cause the slider to drop resulting in death or serious injury by being hit or getting caught in.



Step 2 Remove the plate fixing bolts (6-M3-10) to take off the plate.

Step 2 Removing plate



Step 3 Loosen and remove the left-hand thread bolt (1-M5-12).



CAUTION




As the bolt is left-hand thread type, turn it in clockwise to loosen.

Loosen the set screw (1-M3-5).

Use wrenches (12 mm / 14 mm) to loosen and remove the brake hub.
Wrench (14 mm): for brake hub
Wrench (12 mm): for cut part of ball screw close to the motor.

Skip to "8. Installing brake" when replacing only the brake.

Step 3 Removing brake hub




4. Removing motor

Step 1 Use wrenches (12 mm / 14 mm) to loosen and remove the bearing nut.
Wrench (14 mm): for brake hub
Wrench (12 mm): for cut part of ball screw close to the motor.


Skip this step when the brake hub has been already removed in the previous step.

Step 1 Removing bearing fixing nut



Step 2 Remove the motor fixing bolts (4-M4-16) and ground wire fixing screw (1-M4-8) to pull the stator with bearing out.

▶ Step 2 Removing motor (stator)




Step 3 Pull the rotor out next. When it does not work by hand, pat the end face of the ball screw with a plastic hammer to loosen.



CAUTION
The stator and rotor are a set. Make sure to replace them as a set since a different combination causes an error.

▶ Step 3 Removing motor (rotor)




Skip to "7. Installing motor" when replacing only the motor.

5. Removing ball screw

Step 1 Remove the bolts (4-M4-10) and then plate bearing.

▶ Step 1 Removing plate bearing








Step 2 Remove the screws (2-M4-6) to take off the end cover.

Remove the circlip using circlip pliers.

Remove the bolts (2-M5-20) and then the support block.


Remove the support bearing from the support block.

Step 2 Removing support block and bearing




02 ▶ Step 3 Removing angular bearing

Step 3 Remove the ball screw nut fixing bolts (4-M5-16) and pull out the ball screw from the block.




02 ▶ Step 4 Removing ball screw


Step 4 Remove the key from the ball screw using nippers.




Pull out the angular bearing from the ball screw.



Pull out the bearing plate from the ball screw.



Pull out the ball screw.



This is the end of removing processes. Next step is installing.

6. Installing ball screw

Step 1 Insert the ball screw (N°13) into the carriage.



NOTE




Refer to the tables of "Replacement parts" (P2) for the mentioned numbers written in ().

Insert the bearing plate into the ball screw.

Refer to the photo in the right to match the face of the angular bearing (N°9).


Insert the angular bearing into the ball screw.

Step 1 Installing ball screw



Step 2 Attach the key (N°12) to the ball screw.



Step 2 Installing key



Use pliers on the key protected with waste cloth or else to put into the key all the way.




Step 3 Insert the angular bearing into the block and tighten the bolts (4-M4-10) in a diagonal pattern to fix the bearing plate.

▶ Step 3 Installing bearing plate



Step 4 Insert the support bearing into the support block (Nº10).

▶ Step 4 Installing bearing plate




Insert the support block with installing support bearing into the ball screw.

Attach the circlip (Nº11) into the groove at then of the ball screw using circlip pliers.

Temporarily fix the block with the support block bolts (2-M5-20).




Step 5 Move the carriage close to the non-motor side and temporarily tighten the bolts (4-M5-16) of ball screw nut.



With keeping above, tighten the bolts (2-M5-20) of support block with a torque wrench.

Tightening torque: 7.5Nm



Then tighten the bolts (4-M5-16) of ball screw nut with a torque wrench in a diagonal pattern.

Tightening torque: 7.5Nm



Step 6 Apply appropriate amount of Alvania grease all over the ball screw and move the carriage by hand to make it smooth.




CAUTION Extra grease will be spattered when the robot moves.

7. Installing motor

Step 1 Apply Molybdenum grease onto the shaft part of ball screw. Refer to the photo in the right for the area of applying grease.


▶ Step 1 Installing motor (rotor)



Insert the rotor (N05) into the shaft in the direction shown in the right photo.



CAUTION The stator and rotor are a set. Make sure to replace them as a set since a different combination causes an error.



Step 2 Install the stator inserting jig on the ball screw to insert stator (Nº5).



CAUTION

Take care not to get your fingers caught as the magnet force pulls the stator to the non-motor side after inserting it to a certain extent.



Tighten the motor fixing bolts (4-M4-16) in a diagonal pattern with a torque wrench.

Tightening torque: 3.8Nm



Step 3 Thinly apply Alvania grease around the support bearing (Nº6).

Insert the support bearing (Nº6) into the stator.

Skip to "8. Installing brake" for the models with brake.

Step 4 Confirm the bearing nut direction. The convex surface touches the bearing.


Apply LOCTITE (Nº648 [Green]) onto the threaded part at the end of ball screw, and tighten the bearing nut with a torque spanner (14 mm) and wrench (12 mm).

Tightening torque: 20Nm

Skip to "9. Assembling cover" for the models without brake.





Step 2 Installing motor (stator)



Step 3 Installing bearing



Step 4 Installing Motor (Stator)



8. Installing brake

Step 1 Apply LOCTITE (Nº648 [Green]) onto the threaded part at the end of ball screw on motor side, install the brake hub and tighten it with a torque spanner (14 mm) and wrench (12 mm). Tightening torque: 20Nm




Apply LOCTITE (Nº241 [Blue]) onto the bolts (Nº 3, 1-M5-12, left-hand thread). Fix the ball screw shaft with a wrench (12 mm) to tighten the bolts.



Tighten the set screw (Nº 2, 1-M3-5).


Step 1 Installing brake hub



Step 2 Put the wave washer (Nº4) inside the plate and install it to the stator.

Step 2 Installing plate

Tighten the bolts (6-M3-10) to fix the plate. Tightening torque: 2Nm



▶ Step 3 Installing brake

Step 3 Check the square hole of the brake (N°1).

Insert the brake with matching its hole and the brake hub.


Tighten the bolts (3-M3-35) to fix the brake with taking care not to drop any spacers.

Tightening torque: 2Nm



Install the brake cover and grommet.


Match this hole and brake hub.



Brake



Brake



Brake cover Grommet 3-M3-35 Spacer




9. Assembling cover

Step 1 Fix three types of motor covers with flat head screws (8-M4-8).



Step 1

Assembling cover



End cover Motor cover



End cover 8-M4-8

Fix the end cover with screws (2-M4-6).



Upper cover 2-M4-6

Fix the upper cover with screws (4-M4-8).



4-M4-8

10. Confirming after work

Step 1 Check the grid position.

Refer to "Checking the grid position" of the Maintenance Manual for FLIP-X Series.

Model	Lead (mm)	Standard value (%)
F10	5,10	30 to 70
	20	20 to 80



NOTE

Grid position is within the standard value range:
 ⇒ 11. Confirming position shift
 Grid position is within the standard value range:
 ⇒ Step 2

Step 2 Adjust the grid position.



CAUTION

When adding sims to the motor side, jointly tighten the sims with sandwiched between the bearing plate and damper.




NOTE

- Check the parameter to make sure the origin direction is motor side / non-motor side.
- Replace the damper or adjust the number of sims referring to the tables below as it depends on the lead, origin direction and the result of initial value. Although not required, it is recommended to adjust the grid position. If there is a big gap, it may cause the standard position gap after performing return-to-origin in the future.

Step 2 Removing bearing plate

Motor side



Non-motor side



Damper (Bearing plate)

F10-05(BK)-***

	Return-to-Origin on Motor Side		Return-to-Origin on Non-motor Side	
	Initial Grid Position	Damper Replacement	Initial Grid Position	Damper Replacement
Initial Grid Position	0-29%	71-100%	0-29%	71-100%
Damper Replacement	Change to KX7-M22J2-01	No replacement	Change to KX6-M22J2-00	No replacement
Sim Addition	Add KX7-M2295-00 *1	Add KX7-M2295-00 *1	Add KX6-M2295-00 *1	Add KX6-M2295-00 *1

F10-10(BK)-***

	Return-to-Origin on Motor Side		Return-to-Origin on Non-motor Side	
	Initial Grid Position	Damper Replacement	Initial Grid Position	Damper Replacement
Initial Grid Position	0-29%	71-100%	0-29%	71-100%
Damper Replacement	Change to KX7-M22J2-01	Change to KX7-M22J2-02	Change to KX6-M22J2-01	No replacement
Sim Addition	No addition	No addition	No addition	Add KX6-M2295-00 *2

F10-20(BK)-***

	Return-to-Origin on Motor Side		Return-to-Origin on Non-motor Side	
	Initial Grid Position	Damper Replacement	Initial Grid Position	Damper Replacement
Initial Grid Position	0-19%	71-100%	0-19%	71-100%
Damper Replacement	Change to KX7-M22J2-01	Change to KX7-M22J2-02	Change to KX6-M22J2-01	No replacement
Sim Addition	No addition	No addition	No addition	Add KX6-M2295-00 *2

11. Confirming position shift

Step 1 Connect to the controller and move the robot to the 0 mm position.




CAUTION

Do not enter the safety enclosure and work during the robot servo ON.

Step 2 Check the marking taped in "2. Removing cover". If there is a gap, adjust the origin shift of the controller parameter.

Refer to the manuals for adjusting parameters.

Step 1 **Confirming position shift**



Terms of Use for the Content

Important: Please make sure to read the following carefully.

These Terms of Use for the Content are a legally binding contract between you (whether an individual or a corporation) and Yamaha Motor Co., Ltd. (“Yamaha”) and are the terms and conditions that apply to you when you use documents for Yamaha's industrial robot related products (the “Content”).

If you use the Content, you will be deemed to have agreed to these Terms.

If you do not agree to these Terms, please do not attempt to use the Content.

1. License

(A) Purpose

Yamaha hereby grants to you a (non-exclusive and non-transferable) license (without the right to sub-license) to use the Content to the extent necessary to perform such maintenance or system development of industrial robots or controllers etc. as may be specified in the Content (the “Products”). You must not use the Content for any purpose other than the aforesaid purpose.

(B) How to use the Content

You must not use the Content for such purpose or in such manner as may be detrimental to the interests of Yamaha. When you perform maintenance or system development of the Products using the Content, you must appoint a person who will be in charge of such maintenance or system development, must not allow anyone, other than the appointed person, to use the Content, and must comply with the instructions given in the Content or the safety instructions which form part of the user's manual for the Products.

2. Restrictions

(A) No reproduction allowed

You must not reproduce or translate the Content in whole or in part beyond the extent necessary to perform maintenance or system development.

(B) No change allowed

You must not change the Content or delete the description relating to product identification, copyrights, or any other matters contained in the Content.

(C) No assignment to third parties allowed

You must not sell, offer, lease, or lend the Content to any third party or allow any third party to use the Content. You must not upload the Content to any website or server to which a selected group of people or the public has access or must not translate or adapt the Content or change the programing language of the Content.

(D) Compliance with laws and regulations

You must comply with any and all applicable laws and regulations to the Products including but not limited to the regulation regarding user qualifications, facilities and proper usage.

(E) Export control

You must comply with any and all applicable laws and regulations involving national security and/or export control in pursuing its activity in any way under or in connection with these Terms. You must not, directly or indirectly, export information or material incorporated in the Content to any country outside the country in which you are located or residing.

3. Matters outside the scope of support

Yamaha will not be responsible in any way whatsoever for updates or corrections of the Content or responses to inquiries about the Content. If any updates, improvements, or creations are made by Yamaha, they will form part of the Content and you must also comply with all obligations, restrictions, and terms and conditions under these Terms when you use such deliverables.

4. Intellectual property

(A) Ownership of intellectual property

You acknowledge and agree that Yamaha has the ownership of, and the right to use, all intellectual property relating to the Content (including but not limited to copyrights, trademarks, inventions, devices, patents, trade secrets, designs, and know-how). You also agree that you will not dispute Yamaha's such rights or interests at any time or in any way whatsoever.

(B) Disclaimer of assignment of intellectual property rights etc.

Except for the license set forth in Article 1. (A) above, Yamaha will not grant to you a license to use, or assign to you, any copyrights, trademarks, inventions, devices, patents, trade secrets, designs, or know-how under any of the provisions of these Terms.

(C) Disclaimer of liability for infringing third party rights

You acknowledge and agree that Yamaha will not be liable in any way whatsoever for any infringement or unauthorized use of a third party's intellectual property rights or any legal costs incurred as a result of such infringement or unauthorized use.

5. No warranties

Yamaha will provide the Content to you on an "as is" basis and will not deny the possible existence of defects. Yamaha will not make any warranties, express, implied, or statutory, with regard to the Content (including but not limited to warranties for the Content's merchantability, fitness for a particular purpose, accuracy, integrity, completeness, or freedom from bugs, virus or any other defects). Furthermore, Yamaha will not make any warranties whatsoever with regard to the rights to the Content, appropriability, identicalness to explanations, or non-infringement of other parties' rights.

6. Limitation of liability and remedies

Yamaha will not be liable for any special, incidental, indirect, or consequential damages (including but not limited to loss of profit, loss of information, suspension of business, bodily injury, loss of privacy, or any other monetary or non-monetary damages) suffered by you or a third party in relation to the use of the Content by you or the terms and conditions of these Terms under any theory of liability, tort, contract, or otherwise, and if a claim is made by a third party, you will resolve such claim at your cost and expense and on your responsibility.

7. Termination

If you violate any of these Terms, Yamaha will have the right to suspend the use of the Content by you. In this case, you must comply with the following:

- (1) You must destroy, delete, or return to Yamaha, all of the Content in accordance with the request of Yamaha; and
- (2) You must not claim any compensation or damages against Yamaha or make any other claim or demand to Yamaha for any reason whatsoever.

8. Miscellaneous provisions

(A) Governing law

These Terms shall be governed and interpreted exclusively by the substantive laws of Japan, without regard to the principles of conflicts of law, and without regard to, and not including, the United Nations Convention on Contracts for the International Sale of Goods.

(B) Governing language

These Terms shall be executed in, and controlled in all respects by, the English language. Any translation of these Terms in other language than the English language is provided for your convenience only.

(C) Entire agreement

These Terms, including all supplementary and amended contracts, constitute entire agreement between you and Yamaha with respect to the Content, and integrate, supersede, or exclude all contemporaneous agreements, proposals, representations, or opinions relating to the Content or other subject matters to which these Terms may apply.

(D) Severability

If all or any of the specific provisions of these Terms contain invalid or unenforceable factors, the validity and enforceability of the other provisions will not be affected, and such invalid or enforceable provisions will be deemed to have been replaced with valid and enforceable provisions which may achieve, to the extent possible, the rights and obligations of the parties which are originally contemplated by the parties.

(E) Arbitration

Any disputes, controversies, and/or difficulties that may arise between the parties out of or in connection with these Terms shall be settled amicably between the parties. In the event such amicable settlement cannot be reached within a reasonable time, such dispute shall be determined by arbitration to be held in Tokyo, Japan by the Japan Commercial Arbitration Association pursuant to its arbitration rules. The arbitration panel shall consist of three (3) arbitrators. The language to be used in all aspects of any such arbitration shall be the Japanese or English language. The results of said arbitration shall be final and the arbitral award shall be binding upon the parties hereto. Judgment upon the award may be entered into by any court having jurisdiction over the parties.

(F) Non-waiver

No failure on the part of either party to exercise any right under these Terms will be deemed to be a waiver of such right. The exercise of the rights under these Terms will not affect any other rights or remedies that a party may have or become available to it under these Terms or applicable law.

(G) Compliance with mandatory statute

No provision of these Terms will restrict the exercise of unwaivable rights relating to the Content which may become available to you under mandatory statute.

(H) Survival provisions

Notwithstanding the termination of these Terms, the following provisions will survive such termination; Article 4. Intellectual property, Article 5. No warranties, Article 6. Limitation of liability and remedies, Article 7. Termination, and Article 8. Miscellaneous provisions.

Revision Record

Issue date	Description
Jul. 2020	First edition

Maintenance Procedures

YAMAHA SINGLE-AXIS ROBOT

F10

Jul. 2020

Version 1.00

YAMAHA MOTOR CO., LTD. Robotics Operations

All rights reserved. No part of this publication may be reproduced in any form without the permission of YAMAHA MOTOR CO., LTD.

Robotics Operations

127 Toyooka, Kitaku, Hamamatsu, Shizuoka, 433-8103, Japan
Tel. 81-53-525-8250 Fax. 81-53-525-8378

Robot manuals can be downloaded from our company website.
Please use the following for more detailed information.

<https://global.yamaha-motor.com/business/robot/>

